






REINER

P1-MP







Operating Manual

GB



- ① Weld seam
- ② Zip fastening
- ③ Clip
- ④ Print head
- ⑤ Clip arms
- ⑥ Print head nozzles
- ⑦ Print head contacts

For your safety

 DANGER	Warnings about risks where non-observance of the measures may directly cause death or serious injury .
 WARNING	Warnings about risks where non-observance of the measures may cause death or serious injury .
 CAUTION	Warnings about risks where non-observance of the measures may cause injury .
PLEASE NOTE	Warnings about risks where non-observance of the measures may cause material damage .
	Instructions and tips

Safety instructions for MP ink

WARNING

Special ink is highly flammable. Risk of burns!

- ▶ Store at 10 °C - 20 °C.
- ▶ Do not expose to direct sunlight.

WARNING

If in eyes.

- ▶ Rinse cautiously with water for several minutes.
- ▶ Remove contact lenses, if present and easy to do.
- ▶ Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

1. Making the print head ready for use

1.1. Opening the pack ⇒ Fig. **A**

i The aluminium pouch has a resealable zip fastening ②.

- ▶ With scissors, cut open the top of the pack between the weld seam ① and the zip fastening ②.
- ▶ Unzip ② the pack.
- ▶ Take out the print head ④.

1.2. Releasing the clip ⇒ Fig. **B + C**

The print head ④ is supplied with a reusable clip ③.

- ▶ Place the print head ④ on a firm surface at an angle of about 45° as shown in figure **C**.
- ▶ Hold the red clip ③ by the point with one hand.
- ▶ With the other hand, press the print head ④ down firmly. The clip arms ⑤ will spring out and the print head ④ will slide away from the clip ③.

2. Printing material

For the best results, use material that is clean, non-greasy, dry and at the same temperature as the print head.

i Before carrying out a large print job, perform a test print.

3. Storage ⇒ Fig. **A** + **D**

i MP ink is fast-drying. The time it takes the print head nozzles **6** to dry up depends on the ambient temperature and the humidity.

- If the printing break will probably take more than 5 minutes, the print head **4** should be protected with the clip **3**.
- If the printing break will probably take more than 2 hours, the print head **4** with the clip **3** should be stored in the air-tight aluminium pouch.

- ▶ Remove the print head **4** out of the device.
- ▶ Place the print head **4** with the clip **3** on a smooth and solid surface as shown in figure **D**.
- ▶ Press the print head **4** down until it snaps in the clip **3**.
- ▶ Place the print head **4** into the aluminium pouch and close the zip fastening completely.

i Use the print head within four weeks after opening.

4. Environmental Conditions

Temperature for storage	10°C to +20°C
Temperature for transport	-20 °C to +40 °C (up to 24 hours)

5. Troubleshooting

Dried ink on the print head nozzles ⑥ may result in streaks or reduced print quality.

5.1. Automatic cleaning

- ▶ Read the information about the cleaning of the print head nozzles ⑥ in the manual for the electronic stamp.

5.2. Cleaning the print head nozzles manually

If the automatic cleaning of the nozzles ⑥ does not produce the desired result, we recommend proceeding as follows:

- ▶ To remove dried ink, press a soft cloth, if necessary lightly soaked in ethanol (spirits), against the print head nozzles ⑥ for about 3 seconds.
- ▶ Dab off the dissolved ink and wipe the nozzles dry.

5.3. Reactivating the print head

If ink has dried inside the print head ④ it may be necessary to reactivate it.

- ▶ Lay the print head down on a firm surface protected by a lint-free cloth or piece of material.
- ▶ Place the syringe supplied firmly against the opening on top of the print head ④ and carefully inject a small amount of air (approx. 0.5 ml).

PLEASE NOTE

Risk of staining from discharged ink.

- ▶ Wipe up discharged ink with a lint-free cloth or piece of material.

5.4. Cleaning the print head contacts

In rare cases, dirt on the print head contacts ⑦ may result in inferior printing results.

- ▶ Clean the contacts on the print head ④ and in the device with a soft cloth or cotton bud, if necessary lightly soaked in ethanol (spirits).

Disposal



Directive 2002/96/EC (WEEE)
Electrical and electronic equipment and batteries should not be disposed of along with domestic or general waste. Dispose of equipment in an environmentally friendly way.

Notes



REINER

www.reiner.de

Ernst Reiner GmbH & Co. KG
Baumannstr. 16
78120 Furtwangen
Phone +49(0)7723 657-0
Fax +49(0)7723 657-200
reiner@reiner.de
www.reiner.de

REINER MP BK

4 ml



H226



Danger

Ethanol

Flammable liquid and vapour.



Award for
Operational
Excellence

