

Finger Placement Instructions

The following steps will help increase success rates for fingerprint recognition and help reduce the chance that static electricity will damage the fingerprint sensor.

Do the Two-Step

1 It's always a two-step process. Rest the middle of the finger as shown on the silver bezel.



Step 1

2 Keeping the finger in contact with the silver bezel, bend the finger at the joint and lower your fingerprint onto the fingerprint sensor and follow the instructions on the unit's display.



Step 2



Incorrect

No Crash Landings

Don't bring your finger in for a "Crash Landing". Make sure you always follow the "two-step" process above where you first place the middle of the finger on the bezel and then bend the finger at the joint down onto the sensor.

Other handy tips:

- Ask to have your finger re-enrolled if you continue having problems.
- When enrolling, be in same standing or sitting position as you will be when making actual registrations.